

1

2


3

4

5

6

power 电源	MCCB 塑壳断路器	overcurrent protection 全回路保护	limit switch 限位开关	main contactor 总接触器	frequency converter 变频器	brake resistor 制动电阻	motor protection switch 电机保护
----------	------------	------------------------------	-------------------	---------------------	-------------------------	---------------------	------------------------------



A

B

C

D

1


2

3

4

5

6



由变频器经电缆至操作台
through cable from electrical inverter cabinet to control loop

